



PS/2 Mouse User's Guide

1994-2001 Copyright All Rights Reserved

FCC Statement on CLASS B

Note: This equipment has been tested and found to comply with the limits for a CLASS B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- * Reorient or relocate the receiving antenna.
- * Increase the separation between the equipment and receiver.
- * Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- * Consult the dealer or an experienced radio TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference.
- (2) this device must accept any interference received, including

interference that may cause undesired operation.

1. Hardware Installation

Installing a Mouse with Mouse Port (PS/2) Connector

If you have a mouse with a round mouse port connector, you must turn off the computer before connecting or disconnecting your mouse.

2. Mouse Driver Installation for Windows 95/98/2000/ME & Windows NT 4.0

To install Mouse Driver for Windows 95/98/2000/NT/ME insert the floppy diskette into the floppy drive, click on the Start button, select Run, and type

“A:\SETUP.EXE” (if you insert the Mouse Driver Disk in drive A.)

or type

“B:\SETUP.EXE” (if you insert the Mouse Driver Disk in drive B.)

Follow the on-screen instructions.

*Note- Before installing any software under Windows NT4.0 we recommend you create an Emergency Repair Disk using the Repair Disk Utility provided by the system. (RDISK.EXE)

3. Remove the Windows Mouse Driver

(1) Click the "Uninstall" icon located in the mouse driver folder and follow the on-screen instructions

Or

Use the Add/Remove Programs from within the Windows Control Panel.

(2) The "Uninstall" process will prompt you to change the Mouse Driver during the last step. If you do not change the Mouse Driver, the uninstallation will not remove the Mouse Driver to prevent your mouse from inactivation when you restart your computer. Follow the steps below to change the Mouse Driver before you restart your computer.

Running Windows 95/98/2000/ME or NT 4.0 do the following:

- a) Select "Start".
- b) Select "Settings".

- c) Select "Control Panel".
- d) Select "Mouse" icon.
- e) Select "General".
- f) Select "Change".
- g) Select a new mouse driver that meets your new requirements.

The new setting will over-ride the old ones.

4. Switching Mouse Mode

4-1.Switching Mouse Hardware Modes (Use mode switch)

The Serial Mouse is capable of operating either as a Microsoft Serial Mouse or a Mouse Systems Mouse. At the base of the Mouse you will find a slide switch. The switch has two possible positions, 'MS' and 'PC' When the switch is set to the 'MS' position the Mouse will emulate a two-buttoned Microsoft Mouse while setting the switch to the 'PC' position will cause the Mouse to emulate a three-buttoned Mouse Systems Mouse.

4-2.Switching Mouse Hardware Modes (None mode switch)

As mentioned earlier, the serial mouse is capable of operating either as a Microsoft Serial Mouse or a Mouse Systems Mouse. Which of the two modes the mouse will operate in is determined on the power-on initialization. If any one of the three buttons is depressed during power-on initialization, the mouse will emulate Mouse Systems Mouse. If none of the buttons are depressed during power-on initiation the mouse will emulate Microsoft Mouse.

4-3.Microsoft Mode

When the mouse is in Microsoft mode, only the left and right buttons are Active the middle button is inactive. In this mode, your mouse will correctly emulate a Microsoft Serial Mouse.

4-4.Mouse Systems Mode

If you are a user of AUTOCAD or any other software which gives enhanced performance with a Mouse Systems Mouse you should choose this emulation. A Mouse Systems Mouse operates with all three buttons.

Note: Because Windows 95/98/NT/2000/ME support serial 'MS' mouse mode, you

switch the mouse to 'MS' mode when first installing the mouse driver. After completing the installation, you can switch to 'PC' mouse mode when you restart the computer.

5. Trouble Shooting

Symptom 1 : No mouse movement.

Solution : Make sure the software that you are using supports a mouse.

- Check that mouse is plugged into serial port at the back of computer.
- Ensure that mouse driver is installed on the system.

Symptom 2 : The cursor remains in one spot or moves erratically.

Solution: Check the mouse cable for any breaks or sharp twists. Examine the cable closely where it connects to the mouse.

Symptom 3 : The cursor movement stops at a corner and no longer responds to the mouse movement.

Solution: Run the mouse driver to check which mode the mouse is operating in.

Symptom 4 : Mouse movement does not produce corresponding cursor movement or there is a brief pause during movement.

Solution: Clean the silicon rubber-coated ball and rollers.

Symptom 5: After selecting mouse type the mouse became disabled when clicking "OK" .

Solution : Use the keyboard to close the current window and wait for any instruction to restart your computer. After restarting the mouse should work normally.

Symptom 6: Error Code 115 is displayed when installing the Mouse Driver Software

Solution: Shut down any virus protection software before installing the mouse software.

Symptom 7: Detection Problems with PS/2 Pointing Devices

Solution: If your mouse is connected to the mouse port and is not detected by the system, attempt the following step(s):

- 1) Enable Mouse Port through the Setup Menu (consult your computer documentation for further information.
- 3) If adaptor(s) were not included in your package, your mouse was designed to work on only one type of port

If the problem persists, please check for a possible computer BIOS ROM upgrade from your computer manufacturer.

Some notebook systems, such as IBM Thinkpad, have both an external Mouse Port and an integrated Pointing Stick, which is connected to the Mouse Port. If your mouse is having difficulty running on the Mouse Port of this type of system, try using the serial port instead.

Symptom 8: Conflicts with other Serial Devices

Solution: Some software provided by other manufacturers with mouse functions, such as Logitech MouseWare, may conflict with this mouse. We recommend you remove the software install before installing this mouse software.

Symptom 9: Problems Operating the Wheel

Solution: If your mouse is equipped with a wheel and the wheel does not scroll, verify the following:

- 1) Verify that the "Browser Mouse" or "Mouse Control Panel" application is installed properly. If you do not find the "Browser Mouse" or "Mouse Control Panel" icon in the system tray, you need to reinstall mouse software.
- 2) Some other applications with mouse scrolling function may conflict with this mouse function. Remove these applications before installing this mouse software.

Technical Assistance:

If the above suggestions have not answered your question please contact Memorex Technical Support by email at techsupport@memorex.com or via the telephone at 310-891-1680 Monday-Friday 9am-5pm pacific time.